


Structure of microfiche



1. Read from left to right

2. Title of microfiche (appears on each coordinate)

E 16	Product/assembly/test step	
	Vehicle/engine	

Coordinate

3. Limits of section



Beginning



Mid-section




End



One-page section

4. Purely vehicle-related passages identified by a vertical bar.

5. References to relevant test steps in test specifications; coordinate e.g. C6



A1

Trouble-shooting program



1. Test specifications

1.1 Electric fuel pump

C1

Test step

Test specifications

Fuel delivery


min. 750 cm³/30 s

A2

Test specifications

BMW 318i/518i 4-cylinder engine





p = Control pressure (gauge pressure)
t = Ambient temperature

1.2 Control pressure "cold"

C9

For testing, connect vacuum pump to intake-manifold-pressure connection of warm-up regulator.

Setting value: 510...550 mbar
(385...415 mmHg)

Part no. of warm-up regulator: 0 438 140 005

(Versions for intake-manifold-pressure-controlled full-load enrichment).

A3

Test specifications

BMW 318i/518i 4-cylinder engine



1.3 Control pressure "warm"**C9**

(Versions for intake-manifold-pressure-controlled full-load enrichment).

- Test at atmospheric pressure (without vacuum):

Part no. of warm-up regulator

0 438 140 005

2.7...3.1 bar (2.8...3.2 kgf/cm²)

- For testing, connect vacuum pump to intake-manifold-pressure connection of warm-up regulator.

Setting value:
510...550 mbar
(385...415 mmHg)

Part no. of warm-up regulator

0 438 140 005

3.4...3.8 bar (3.5...3.9 kgf/cm²)

* Pressures in the test specification table are given in bar (gauge pressure) and/or in kgf/cm² (gauge pressure)



Test step

Test specifications*

1.4 Leak test on full-load diaphragm

C24

Setting value:
510...550 mbar
(385...415 mmHg)

Part no. of warm-up regulator
0 438 140 005

Maximum pressure drop 100 mbar (75 mmHg)/15 s

1.5 Primary pressure

D2

Part no. of fuel distributor		
0 438 100 078	} Checking value	4.5...5.2 bar
		(4.6...5.3 kgf/cm ²)
0 438 100 101	} Setting value	4.7...4.9 bar
		(4.8...5.0 kgf/cm ²)

1.6 Leak test

D10

Minimum pressure	20 cm ³ accumulator 0 438 170 007	40 cm ³ accumulator 0 438 170 019/021
after 10 min:	1.9 bar(2.0 kgf/cm ²)	2.0 bar(2.1 kgf/cm ²)
after 20 min:	1.7 bar(1.8 kgf/cm ²)	1.7 bar(1.8 kgf/cm ²)

1.7 Injection valves

E1

0 437 502 006
Opening pressure: 2.7...3.8 bar
(2.8...3.9 kgf/cm²)

* Pressures in the test specification table are given in bar (gauge pressure) and/or in kgf/cm² (gauge pressure).

A5

Test specifications

BMW 318i/518i 4-cylinder engine



Test step

1.8 Fuel distributor

E10

Comparative measurement of deliveries from outlets:

Fuel distributor No. 0 438 100 078	Setting point cm ³ /min.	Max. allowable delivery cm ³ /min.
Idle	6.0	6.7
Part load	40.0	43.0
Full load	125.0	137.0

Fuel distributor No. 0 438 100 101	Setting point cm ³ /min.	Max. allowable delivery cm ³ /min.
Idle	6.0	6.6
Part load	40.0	43.0
Full load	110.0	121.0

1.9 Idle adjustment *

F1

Idle speed

318i Europe model:	<u>850... 950 min⁻¹</u>
318i/518i Sweden, Australia model:	<u>900...1000 min⁻¹</u>

CO Concentration

318i Europe model:	<u>0.5...1.5 % by vol.</u>
318i/518i Sweden, Australia model:	<u>1.0...2.0 % by vol. without exhaust-gas recirculation</u>


* Engine at normal operating temperature
Air conditioner switched off.

A6

Test specifications

BMW 318i/518i 4-cylinder engine





- | | |
|--------------------------|------------------------|
| 1 = Start valve | 5 = Pre-supply pump |
| 2 = Thermo-time switch | 6 = Electric fuel pump |
| 3 = Warm-up regulator | 7 = Electronic relay |
| 4 = Auxiliary-air device | 8 = Ignition coil |


2. Electrical safety circuit

2.1 Circuit diagrams

● BMW 318i/518i 1980 models

The safety circuit employs an electronic relay which is energized from terminal 1 of the ignition coil.





438/0819

● BMW 318i/518i as of 1981 model

- | | |
|-------------------------------|--------------------------|
| 1 = Electronic relay | 6 = Thermo-time switch |
| 2 = Prolonged-injection relay | 7 = Warm-up regulator |
| 3 = Ignition coil | 8 = Auxiliary-air device |
| 4 = Thermo-switch | 9 = Pre-supply pump |
| 5 = Start valve | 10 = Electric fuel pump |

Additional thermo-switch. Switching temperature 0°C.
 At temperatures below 0°C the thermo-switch is closed and the prolonged-injection relay operates.
 At temperatures above 0°C the thermo-switch is open and the prolonged-injection relay does not operate.






2.2 Bridging the safety circuit

In order to carry out testing with the engine stationary, it is necessary to bridge the safety circuit.

To do this pull the electronic relay (arrow), positioned on the left hand side on the wheel arch, out of its base.






438/0639

Connect contacts 15 and 87 in the base with a bridge.

Use connecting cable 1.5 mm² with fuse holder and 16 A fuse (to be user-fabricated according to sketch).

Electric fuel pump, warm-up regulator, auxiliary-air device and pre-supply pump are now supplied with battery voltage.





3. Diagram of fuel lines

• Europe model

- | | | |
|--------------------------|--------------------------|--|
| 1 = Fuel tank | 6.1 = Air-flow sensor | 11 = Thermo-time switch |
| 2 = Pre-supply pump | 6.2 = Fuel distributor | 12 = Throttle valve |
| 3 = Electric fuel pump | 7 = Injection valve | 13 = Idle-speed adjusting screw (bypass) |
| 4 = Fuel accumulator | 8 = Warm-up regulator | 14 = Idle-mixture-adjusting screw |
| 5 = Fuel filter | 9 = Auxiliary-air device | 15 = Primary-pressure regulator with push-up valve |
| 6 = Mixture-control unit | 10 = Start valve | 16 = Anti-tamper cap |

A11


Diagram of fuel lines
BMW 318i/518i 4-cylinder engine



A12

Diagram of fuel lines
BMW 318i/518i 4-cylinder engine





● Sweden and Australia model

- | | | | |
|--------------------------|--------------------------|--|--|
| 1 = Fuel tank | 6.2 = Fuel distributor | 13 = Idle-speed adjusting screw (bypass) | Exhaust-gas recirculation
C = Thermo-valve
D = Solenoid-operated valve
E = Speed relay
F = Recirculation valve
G = Pressure converter |
| 2 = Pre-supply pump | 7 = Injection valve | 14 = Idle-mixture adjusting screw | |
| 3 = Electric fuel pump | 8 = Warm-up regulator | 15 = Primary-pressure regulator with push-up valve | |
| 4 = Fuel accumulator | 9 = Auxiliary-air device | 16 = Anti-tamper cap | |
| 5 = Fuel filter | 10 = Start valve | Secondary-air induction | |
| 6 = Mixture-control unit | 11 = Thermo-time switch | A = Non-return valve | |
| 6.1 = Air flow sensor | 12 = Throttle valve | B = From air filter | |

A13

Diagram of fuel lines
BMW 318i/518i 4-cylinder engine



A14

Diagram of fuel lines
BMW 318i/518i 4-cylinder engine



4. General information

4.1 Introduction

The vehicles BMW 318i and 518i are supplied with 1.8 l 4-cylinder engine with K-Jetronic in the following versions:

318i European version	from 1981 model
318i Swedish and Australian versions	from 1980 model
518i Swedish version	from 1980 model

This repair manual refers only to the above-mentioned vehicles and gives a concise description of the testing and adjustment operations to be performed on the vehicle on the K-Jetronic.

All the system components are dealt with in separate working steps with the corresponding test specifications. In addition to this repair manual the appropriate testing and repair manuals will, of course, be issued for every other vehicle type equipped with the K-Jetronic.

The K-Jetronic differs from other known fuel-injection systems in terms of both construction and operation. In order to be able to carry out the testing procedures described in this manual - and therefore to be able to assess the components - the K-Jetronic and its operation should be clearly understood. The essential points of the operation and construction of the K-Jetronic are described in Technical Instruction VDT-U 3/1 En.



When trouble-shooting the K-Jetronic, it is assumed that the ignition is in order and that the engine is in proper mechanical condition.

The individual test steps of this repair manual are detailed and self-contained. This permits direct trouble-shooting without having to go through the entire test program for each fault.

The trouble-shooting chart on Coordinates B 1 - B 4 is intended to make it easier to decide which test steps have to be carried out for certain faults.

According to the symptom stated by the customer or which you yourself have determined, select the possible cause in the trouble-shooting chart. The coordinate at the end of the cause column refers to the appropriate test step with the associated test specification.

Important note:

If any fuel connections are loosened, parts removed, also on the vacuum system, always use new seals when re-connecting or re-installing.

Ensure utmost cleanliness when working on the K-Jetronic. Fuel connections must be cleaned thoroughly on the outside before opening.



4.2 Design

The entire system of the K-Jetronic in these vehicle types corresponds, with the exception of the differences listed below, to the basic design as described in Technical Instruction VDT-U 3/1 En.

4.3 The following components are different or extra:

- Electric fuel pump with replaceable non-return valve.
- Fuel accumulator 0 438 170 007 with 20 cm³ storage volume.
Fuel accumulator 0 438 170 019/0 438 170 021 with 40 cm³ storage volume.
On accumulator 0 438 170 019 the spring chamber is vented to atmosphere by a screw.
On accumulators 0 438 170 007/0 438 170 021 the spring chamber is connected by a hose piece to the intake line of the electric fuel pump.
- 4-cylinder mixture-control unit with updraft air-flow sensor.
- Fuel distributor with adjustable differential-pressure valves. In this type of fuel distributor, screw plugs are situated adjacent to the fittings for the fuel-injection lines.
This possibility for adjustment has only been introduced for production at the works. This does not result in any additional adjustment possibilities for the After-Sales Service Organization. For this reason, the fuel distributor is to be dealt with in precisely the same manner as the conventional model.
The screwplugs must not be removed or loosened.



- Pre-supply pump in fuel tank.
When testing the electric fuel pump (fuel delivery test), any possible influence of the pre-supply pump is to be taken into consideration.
- Warm-up regulator 0 438 140 005 for intake-manifold-pressure-controlled full-load enrichment.
Intake-manifold connection on top part of housing.
- Electrical safety circuit. The components - electric fuel pump, warm-up regulator and auxiliary-air device - are controlled by an electronic relay. This makes sure that, when the engine is stopped and the ignition is switched on, the electric fuel pump does not start up and the warm-up regulator and auxiliary-air device do not shut off prematurely.
- As of the 1981 model 0°C thermo-switch and prolonged-injection relay.
Due to the so-called prolonged-injection relay the start valve injects during cold starting (only at temperatures below 0°C) not only during the starting period, but during the entire switching time of the thermo-time switch.

4.4 Other equipment

- The Sweden and Australia model is equipped with exhaust-gas recirculation and Pulsair secondary-air induction.
Both systems contribute toward reducing the exhaust emissions.
Both systems must be rendered inoperative for the idle adjustment/test.



5. Test equipment and tools

- Pressure tester KDJE-P 100 (previously KDEP 1034).
For testing all fuel pressures and testing for leaks.
- Connecting-parts set KDJE-P 100/10 (previously KDEP 1034/10).
For connecting pressure tester to the control-pressure port of the fuel distributor.
- Adjusting wrench KDEP 1035.
For adjusting the idle-mixture-adjusting screw in the mixture-control unit (CO-adjustment).
- Guide ring KDEP 1040/10 (dia. 80 mm)
For centering the air-flow sensor plate in the air-flow sensor.
- Tester for delivered quantity comparison KDJE-P 200 (previously KDJE 7451).
For comparing the fuel delivered from the individual fuel-distributor outlets.
- Graduate (commercially available, capacity approx. 1.5 l)
For measuring the delivery of the electric fuel pump.
- Electric connecting cable (test lead).
KDJE 7450/70 for the direct connection of components to be tested, e.g. cold-start valve.
- Set of tools for the removal and fitting of idle-CO-anti-tamper device of air-flow sensor.
(e.g. No. 131090 from the firm Cartool, Hans Schubert KG, Unterer Grasweg 88/D-8070 Ingolstadt).



- Valve tester KDJE-P 400 (previously KDJE 7452).
For testing the injection valves.

Test media: Calibrating fluid (Shell K 30, Esso-Varsol, Shell Mineral Spirits 135) or Bosch, Part Designation VS 14942-CH
Previously Part No. 5 973 340 650
The Bosch calibrating fluid can be obtained in 5 l metal cans from the following supplier:
Firma
Oskar Gnamm GmbH & Co
D-7531 Kämpfelbach-Bilfingen

Caution:


For safety reasons, never use normal gasoline or similar easily inflammable and combustible liquids.

Even with calibrating fluid, be sure to observe the local official regulations.

- Tachometer (commercially available)
For idle-speed adjustment.
- CO meter (commercially available)
For idle-speed CO adjustment.
- Vacuum pump (commercially available)
For testing the warm-up regulators with full-load enrichment dependent on intake-manifold pressure, e.g. the vacuum hand-operated pump from

Firma Korinth
Ludwig-Kloos-Strasse 21
6450 Hanau 7 (Steinheim)






- 1 = Mixture-control unit
- 2 = Thermo-time switch
- 3 = Injection valve

6.. Installation position of individual components

6.1 Arrangement of components on engine Air filter removed.






- 1 = Start valve
- 2 = Thermo-time switch
- 3 = Auxiliary-air device

A22

Installation position of components
BMW 318i/518i 4-cylinder engine






Warm-up regulator (arrow)

Picture taken from underneath vehicle

A23

Installation position of components
BMW 318i/518i 4-cylinder engine





- 1 = Electric fuel pump
- 2 = Fuel accumulator
- 3 = Fuel filter

6.2 Fuel-supply components

Electric fuel pump, fuel accumulator and fuel filter are located on a common support piece above the rear axle on the right-hand side (as viewed from behind the vehicle).

Before replacing one of these components, the connections should be thoroughly cleaned.

Before releasing the connections, pinch off intake hose of electric fuel pump so that no fuel can escape (e.g. using hose clammer W 157 from Matra Co.).



7. Trouble-shooting chart (see also Coordinates (B 3/B 4))

Customer complaint (fault symptom)

1. Engine does not start, or starts poorly, in cold condition
2. Engine does not start, or starts poorly, in warm condition*
3. Irregular idling during the warm-up phase (shakes)
4. Irregular idling with warm engine (shakes)
5. Engine does not draw gas, burbles
6. Engine misfires when operating on the road, high load
7. Insufficient power

*Note:

If, in the case of Symptom 2, after checking and repairing all the fault causes listed below, the hot-start characteristic is still unsatisfactory this can be improved by fitting an impulse relay. The fitting of this relay is described in Coordinates L 5

Cause							Coordinates
●	●	●	●	●	●	Vacuum system leaking	B 5
●	●	●	●	●	●	Air-flow sensor lever and/or control plunger not moving smoothly	B 7
●	●	●	●	●	●	Position of the air-flow sensor plate incorrect	B 17
●	●	●	●	●	●	Auxiliary-air device does not open	B 22
●	●	●	●	●	●	Electric fuel pump not operating	C 1
●	●	●	●	●	●	Cold-start system defective	C 5
●	●	●	●	●	●	Cold-start valve leaking	C 7
●	●	●	●	●	●	Excessive fuel delivery for control-pressure circuit	C 11
●	●	●	●	●	●	"Cold" control pressure outside tolerance	C 9
●	●	●	●	●	●	"Warm" control pressure too high (after warm-up)	C 9
●	●	●	●	●	●	"Warm" control pressure too low (after warm-up)	C 9
●	●	●	●	●	●	Primary (system) pressure outside tolerance	D 2
●	●	●	●	●	●	Overall fuel system leaking	D 10
●	●	●	●	●	●	Injection valves leaking, opening pressure too low	E 1
●	●	●	●	●	●	Unequal fuel delivery (imbalance of fuel delivery)	E 10
●	●	●	●	●	●	Basic idle adjustment incorrect	F 1
●	●	●	●	●	●	Throttle plate does not open completely	F 1

B1

Trouble-shooting chart

BMW 318i/518i 4-cylinder engine



B2

Trouble-shooting chart

BMW 318/518i 4-cylinder engine



8. Engine runs on after being switched off ("diesels")

9. Fuel consumption too high

10. Flat spot during acceleration

11. CO concentration during idling too high

12. CO concentration during idling too low

13. Idle-speed cannot be adjusted (too high)

14. Engine starts but then immediately stops

							Cause	Coordinates
		●		●			Vacuum system leaking	B 5
●		●	●	●			Air-flow sensor and/or control plunger not moving smoothly	B 7
●							Position of the air-flow sensor plate incorrect	B 17
							Auxiliary-air device does not open	B 22
					●		Auxiliary-air device does not close	B 22
						●	Electric fuel pump not operating	C 1
							Cold-start system defective	C 5
●	●		●				Cold-start valve leaking	C 7
		●				●	Excessive fuel delivery for control-pressure circuit	C 11
		●				●	"Warm" control pressure too high (after warm-up)	C 9
	●	●	●			●	"Warm" control pressure too low (after warm-up)	C 9
		●				●	Primary (system) pressure outside tolerance	D 2
							Overall fuel system leaking	D 10
●							Injection valves leaking, opening pressure too low	E 1
		●					Unequal fuel delivery (imbalance of fuel delivery)	E 10
●	●	●	●	●			Basic idle adjustment incorrect	F 1
							Throttle plate does not open completely	F 1

B3

Trouble-shooting chart


BMW 318i/518i 4-cylinder engine

**B4**

Trouble-shooting chart

BMW 318i/518i 4-cylinder engine





Working steps

8. Check the vacuum system of the engine for leaks.

The arrows in the diagram show typical points where leaks can occur.

Check by performing a visual inspection or, in cases of doubt as follows: Disconnect the hose from the outlet of the auxiliary-air device and blow air through this hose into the intake system using a compressed-air gun. The throttle valve is to be fully open. Brush connection points with soapy water, or spray with leak detector (e.g. Gupoflex).

Under no circumstances may combustible liquids be used when testing for leaks.

The formation of bubbles or foam indicates a leak.

If a leak has been eliminated, it is necessary finally to adjust the idle speed with the engine at normal operating temperature: Idle-speed adjustment is described on Coordinates F 12.

B 5

Leak test on air-intake system
BMW 318i/518i 4-cylinder engine



B 6

Leak test on air-intake system
BMW 318i/518i 4-cylinder engine




9. Check the control lever in the air-flow sensor and the control plunger in the fuel distributor for ease of movement.

9.1 Preparations

- Engine temperature not below +20°C.
- Remove the rubber hood so that the air-flow sensor plate becomes accessible.
- Switch on the electric fuel pump for approx. 10 seconds by bridging the safety circuit.
This results in application of the control pressure to the control plunger in the fuel distributor.





9.2 Check that the control lever moves freely

Raise the air-flow sensor plate by hand (updraft) and release again. The sensor plate snaps back into the zero position and bounces up about twice from the spring-loaded stop. If the control lever does not move freely, first release all fastening screws holding the air-flow sensor to determine whether housing deformation is the cause of the problem.

If the problem is solved by loosening the fastening screws, the seal between the air-supply housing and air-flow sensor should be changed (BMW- parts).

Tighten the screws uniformly cross-wise to a torque of 9...10 Nm (0.9...1.0 kgfm).


If the housing is not deformed, then the air-flow sensor must be repaired or replaced.

B8

Air-flow sensor/fuel distributor

BMW 318i/518i 4-cylinder engine





9.3 Check that the control plunger moves freely

Raise the air-flow sensor plate by hand (updraft). The same resistance must be felt over the entire movement.

Move the sensor plate rapidly back to a position just in front of the zero stop. The control plunger follows only sluggishly, but must make noticeable contact with the sensor plate lever. If this condition is fulfilled, the control plunger can be considered to move freely.

If the control plunger does not move freely, remove the fuel distributor from the air-flow sensor.



Important!

Note the following when installing fuel components and fuel lines:

Always ensure utmost cleanliness when loosening or tightening the fuel connections. No dirt must enter the fuel system.

When loosening or tightening the fuel connections, apply counter-force at the fixed hexagon of the component.


Clean the fuel distributor thoroughly in the region of the fuel connections. Screw off all connections.

B 10

Air-flow sensor/fuel distributor

BMW 318i/518i 4-cylinder engine






Screw out three fastening screws and remove the fuel distributor from the air-flow sensor.

Remove the plunger. Under certain conditions, in order to do this it may be necessary to blow compressed air briefly against the plunger through the control-pressure connection hole. Hold the plunger with your hand while doing this. Clean the plunger thoroughly with benzine. If the plunger still does not move freely, replace the fuel distributor

B11

Air-flow sensor/fuel distributor
BMW 318i/518i 4-cylinder engine





1 = Anti-drop-out device
2 = Control plunger

9.4 Fuel distributor with anti-drop-out device for the control plunger


Caution!

The fuel distributors have an anti-drop-out device for the control plunger.

This also protects the plunger in transit and facilitates installation.

The anti-drop-out device must not be removed!






9.5 Fitting the fuel distributor

When fitting the fuel distributor, use a new seal ring between fuel distributor and air-flow sensor.

Observe the tightening torque 3.2...3.8 Nm (0.32... 0.38 kgfm) for the fastening screws precisely.

When connecting the fuel-injection tubing, use new seal rings.






- 1 = Mixture-control screw
- 2 = Guide tube
- 3 = Lead seal

9.6 Matching the fuel distributor to the air-flow sensor for initial starting

Screw off one fuel-injection line from the fuel distributor.


Bridge the electrical safety circuit so that the electric fuel pump operates.

The idle-mixture-adjusting screw is adjusted via a guide tube rigidly fitted on the mixture-control unit.



- 1 = Idle-mixture-adjusting screw
- 2 = Guide tube
- 3 = Lead seal

Remove anti-tamper device (lead seal) of the idle-mixture-adjusting screw. Introduce adjusting wrench KDEP 1035 through the hole into the idle-mixture-adjusting screw.



Screw in the idle-mixture-adjusting screw slowly and without exerting any great pressure on the adjusting wrench until fuel is just delivered from the open outlet (arrow) of the fuel distributor. Then turn back the idle-mixture screw by 1/2 turn.

Re-connect the fuel-injection line to the fuel distributor, start the engine and warm up.

The final matching of air-flow sensor and fuel distributor is carried out by adjusting the idle speed with the engine at normal operating temperature.

Idle-speed adjustment is described on Coordinates F 19.




10. Checking and adjusting the position of the air-flow sensor plate

10.1 Preparations

- Engine temperature is not important.
- Remove the rubber hood fitted between the air-flow sensor and the throttle-valve assembly (release 2 clamping bands), so that the air-flow sensor plate becomes accessible.






10.2 Centering the air-flow sensor plate

Check that the sensor plate is flat (not bent) and that it can move through the narrowest part of the air funnel without touching the funnel. If necessary, center it using a positioning ring KDEP 1040/10 (dia. 80 mm) as follows:

Loosen the sensor plate fastening screw. Insert the positioning ring while holding the fastening screw with pliers so that the sensor plate does not deflect downwards.






With the positioning ring in place, tighten the fastening screw with a torque of 5.0...5.5 Nm, loosen again and tighten again with the same torque.

When tightening the screw make sure that the air-flow sensor plate is in zero position (in the cylindrical part of the air funnel).


It must no longer be possible to turn the air-flow sensor plate by hand.



Caution:

Be sure that sensor plate is mounted in correct position! Its upper side is identified by five punch marks (in a row). The sharp edge (arrow) is at the bottom.





438/0374

10.3 Checking and adjusting the zero position of the sensor plate (rest position):

Switch on the electric fuel pump for approx. 10 seconds by bridging the safety circuit.

This results in application of the control pressure to the control plunger in the fuel distributor.


The upper edge of the sensor plate must be flush with the cone in the position marked with a circle in the picture. A lower position of up to maximum 0.5 mm is permissible, however the air-flow sensor plate must not project at any point on its circumference outside the cylindrical part of the air funnel.

If necessary, the position of the leaf-spring limit-stop can be corrected by adjusting the shaped spring (arrow).

B21

Checking/adjusting air-flow sensor plate
BMW 318i/518i 4-cylinder engine





438 / 0375

- 1 = Auxiliary-air device
- 2 = Flashlight
- 3 = Mirror

11. Checking the operation of the auxiliary-air device.

The engine must be cold.

Disconnect the electric cable plugs from the auxiliary-air device and warm-up regulator.

Disconnect both air hoses from the auxiliary-air device. Since the two hose fittings on the auxiliary-air device are located exactly opposite each other, a visual check can now be made to see if the blocking plate is partially open.


It will be easier to look through the auxiliary-air device with the aid of a flashlight and a mirror, as shown in the illustration.



- If an opening is not visible with the engine cold, replace the auxiliary-air device.
- Fit the electric cable plug on the auxiliary-air device.
- By bridging the electrical safety circuit, supply power to the auxiliary-air device.
After a maximum of 10 minutes, the opening in the auxiliary-air device must be completely closed by the blocking plate.
- If the blocking plate does not close, check the power supply (open circuit, voltage drop).
Minimum voltage across the connector 11.5 V with the engine stopped.
- If these points are O.K., check the heating coil of the auxiliary-air device for an open circuit using an ohmmeter.
- Replace the auxiliary-air device if defective.

When the auxiliary-air device has been replaced, readjust the idle speed with the engine at normal operating temperature. Idle adjustment is described on Coordinates F 1.






12. Checking the operation of the electric fuel pump.

12.1 Requirement

Conclusive information on the operation of the electric fuel pump can only be given by a measurement of fuel delivery under pressure, i.e. under primary (system) pressure. This measurement must therefore be made at the return line leading to the fuel tank (arrow).



12.2 Measuring point

A suitable measuring point for fuel-delivery testing is the return port (arrow) on the fuel distributor.

Unscrew the fuel return line from the fuel distributor. Equip a test hose (minimum inside diameter 8 mm) with an inlet union and union nut M 12 x 1.5 and connect to the return port of the fuel distributor.

Hold the end of the hose in a graduate (approx. 1.5 litres capacity) in order to make the measurement.



12.3 Testing:

Remove the plugs from the warm-up regulator and auxiliary air device. Switch on the electric fuel pump for precisely 30 seconds by bridging the safety circuit and measure the delivery in a graduate.

12.4 Test specification:

Fuel delivery: min. 750 cm³/30 seconds

12.5 Possible causes of insufficient fuel delivery:

- Power supply to the electric fuel pump defective, voltage drop. Necessary minimum voltage at terminal with pump operating = 11.5 V.
- Fuel filter very dirty.
- Primary pressure too high.

The thus caused pressure drop which increases with time leads to the formation of gas bubbles and noisy running. In addition, with this prefilter it is possible for particles of adhesive to come away, which leads to the blocking of the fuel pump and to the breaking of the driver.

Warranty claims should be rejected for the above-mentioned fuel pumps which are brought in due to noise and blocking.

If the above-mentioned points are O.K., the cause lies with the electric fuel pump itself.
Replace the electric fuel pump.




12.6 Removal and installation of the electric fuel pump:

Pinch off the fuel intake hose from the fuel tank to the electric fuel pump (e.g. using hose clammer W 157 from Matra Co.).

When installing, use a new seal and pay attention to the correct positioning of the electric fuel pump. Danger of bending the fuel lines.







13. Checking the cold-start system (thermo-time switch, cold-start valve).

13.1 Thermo-time switch

Remove the thermo-time switch (arrow) for testing. It is to be found on the forward end face of the cylinder head in the cooling-water distribution fitting. Collect any escaping coolant in a container.





438/0466

The switching temperature $+35^{\circ}\text{C}$ and the switching time at -20°C of 8 seconds are stamped into the hexagonal section of the thermo-time switch.


The removed thermo-time switch is tested using the ohm-meter in accordance with the specifications given below. The temperatures for the thermo-time switch can easily be obtained with water. Cooling takes place in a freezer chest.

		Resistance measurement (Ω) between		
At a temperature below $^{\circ}\text{C}$	above $^{\circ}\text{C}$	Term. "G" and "ground" (housing)	Term. "W" and "ground" (housing)	Term. "G" and term. "W"
+30		25...40	0	25...40
	+40	50...80	100...160	50...80

C6

Checking cold-start sys./t.-t. switch
BMW 318i/518i 4-cylinder engine





13.2 Start valve:

Remove the start valve. Hose line remains connected. Pull off the plug and connect the start valve directly to ground and to terminal 15 (e.g. at the ignition coil) using connecting cable KDJE 7450/70.

Important note:

During this test, do not let the connecting cable touch B +. Danger of fire due to sparking!

Hold the start valve in a suitable container (e.g. the graduate).

Switch on the electric fuel pump by bridging the safety circuit.

Switch on the ignition (max. 30 seconds). The start valve must now open and spray fuel.



Switch off the ignition. Remove the electric connecting cable and dry the nozzle of the start valve. The safety circuit remains bridged so that the primary pressure is applied to the start valve.

No droplets of fuel must drip from the nozzle of the start valve during the next minute. Even if shaken and knocked, the start valve must not leak. Then switch the electric fuel pump off again. Replace the start valve if it does not open or if it leaks.

13.3 Thermo-switch (only from 1981 model)

The thermo-switch (not made by Bosch) is tested with a test lamp or ohmmeter.

At temperatures above $+5^{\circ}\text{C}$ the contact must be open. At temperatures below -8°C it must be closed.

Replace the thermo-switch if defective.

When a leaky start valve or a defective thermo-time switch has been replaced, carry out the idle adjustment with the engine at normal operating temperature. Idle adjustment is described on Coordinate F 1.



14. Checking the control pressures

14.1 Preliminary remarks:

The control pressures tested in the following are in each case governed by the warm-up regulator. If the test results are incorrect, however, this may also be due to faults which have nothing to do with the warm-up regulator.

These possible faults are:


- No or too low a voltage at the electric connector.
- Fuel return from the warm-up regulator blocked or constricted.
- Too high a fuel delivery for the control-pressure circuit.

The testing of this control-pressure delivery is described as an additional test step at the beginning of the control pressure tests.

Test specification: 160...240 cm³/min.

Reference is made to the other possible causes of trouble in the respective test step.






- 1 = Return connection (M 8 x 1)
- 2 = Inlet connection (M 10 x 1)
- 3 = Connection for intake-manifold pressure (downstream of throttle valve)
- 4 = Electric connection

14.2 Warm-up regulator versions

- Warm-up regulator No. 0 438 140 005

The warm-up regulator is a version for intake-manifold-pressure-controlled full-load enrichment. This means that the cold and warm control pressures are additionally influenced by the intake-manifold pressure acting on the full-load diaphragm of the warm-up regulator. The intake-manifold connection port (3) is on the top of the housing cover.



438/0379

14.3 Checking the fuel delivery for the control-pressure circuit:

Before testing: Make sure that the electric fuel pump is operating properly. Test specification: min. 750 cm³/30 s.

Unscrew the control-pressure line (to the warm-up regulator) from the fuel distributor.

Screw connecting piece (thread M 8 x 1/M 12 x 1.5) from connecting parts set KDJE-P 100/10 onto control-pressure port. Connect one of the two connecting hoses of the pressure tester KDJE-P 100 (previously KDEP 1034) to the connecting piece on the fuel distributor (thread M 12 x 1.5) and hold hose in graduate (approx. 0.5 litre capacity).




Switch on the electric fuel pump for 1 minute precisely by bridging the safety circuit. Measure delivery.

Test specification: 160...240 cm³/min.

If the measured value is outside tolerance, the fault is in the fuel distributor.

Replace the fuel distributor.






14.4 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034):

The pressure tester KDEP 1034 is equipped with a three-way valve with 2 separate valve screws. The connections of the directional-control valve are numbered (Fig. a). Since the end of 1979 the pressure tester KDJE-P 100 has been supplied. Its directional-control valve has only one valve screw (Fig. b). The connections of this directional-control valve are identified by symbols:
 A = Inlet (from the fuel distributor)
 B = Outlet (to the warm-up regulator)
Caution:

When the directional-control valve is not in use, always keep the valve screw(s) open in order to relieve the pressure on the seal rings.



The directional-control valve of the pressure tester is connected into the control-pressure line from the fuel distributor to the warm-up regulator.

Install using connecting-parts set KDJE-P 100/10 (previously KDEP 1034/10).


Screw the adapter (1) with seal ring onto the outlet fitting B or 1 of the directional-control valve.

Unscrew the control-pressure line (2) from the fuel distributor and connect to the adapter with inlet-union screw M 8x1 and seal rings.

Screw the connecting piece (3) of the connecting-parts set into the control-pressure connection port of the fuel distributor and connect to inlet fitting A or 3 of the directional-control valve via hose line (4).

Suspend the pressure gauge from the engine-compartment lid (possibly using a wire hook).






14.5 Bleeding the pressure tester

Disconnect the electric plug from the warm-up regulator. Let the pressure gauge hang down (hose fully extended).

Switch on the electric fuel pump by bridging the electrical safety circuit.

Open and close the valve screw(s) of the directional-control valve in a 10-second rhythm about 5 times.

Then hang the pressure gauge from a suitable support (e.g. from one of the struts under the engine hood). Open valve screw of directional-control valve (both screws in the case of KDEP 1034) (turning to the left).



a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

14.6 Testing the "cold" control pressure:


Warm-up regulator: 0 438 140 005

The test is performed with the engine switched off. The engine must be cold. For this purpose, the engine should have been switched off for several hours, preferably overnight.

Pull off the plug from the warm-up regulator.

Open the valve screw of the directional-control valve (both screws in the case of KDJEP 1034).

Switch on the electric fuel pump by bridging the electrical safety circuit.




Part No. of warm-up regulator: 0 438 140 005

The control pressure is checked with simulated intake-manifold pressure, i.e. vacuum is applied to the warm-up regulator.

To do this, connect the vacuum pump to the intake-manifold-pressure connection port of the warm-up regulator on the top of the housing. The picture shows testing with the recommended Mityvac hand vacuum pump.

Setting value for testing: 510...550 mbar
(385...415 mmHg)

The "cold" control pressure is indicated on the pressure gauge of the pressure tester.



p = Control pressure (bar or kgf/cm² gauge pressure)
t = Ambient temperature (°C)

Warm-up regulator Part No.: 0 438 140 005

Calculate the nominal control pressure in accordance with the ambient temperatures in the graph.

Example: Ambient temperature = 20°C
Nominal control pressure = 1.4...1.8 bar
gauge pressure




If the measured "cold" control pressure differs from the nominal value, this may be due to one of the following faults:

- Fuel delivery for the control-pressure circuit too low or too high.
Test fuel delivery.
Test value: 160...240 cm³/min.
- Fuel return from the warm-up regulator blocked or constricted (if control pressure too high).
Eliminate constriction.
- Warm-up regulator defective. Replace warm-up regulator.

When the warm-up regulator has been replaced or a fault remedied, carry out the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinates F 1.






a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

14.7 Checking the "warm" control pressure

Warm-up regulator Part No.: 0 438 140 005

The test is performed with the engine switched off, once without intake-manifold pressure being applied, once with simulated intake-manifold pressure (vacuum) applied.

Open the valve screw of the directional-control valve (or both valves in the case of KDEP 1034).



- Warm-up regulator Part No. 0 438 140 005

For testing with simulated intake-manifold pressure, connect the vacuum pump to the intake-manifold-pressure connection port of the warm-up regulator (on top of the housing, next to the plug housing).

The picture shows the recommended Mityvac hand pump.

Setting value for the test: 510...550 mbar
(385...415 mmHg)

Test procedure:

The temperature of the engine is not important.
Open the valve screw of the directional-control valve (both in the case of KDEP 1034).
Switch on the electric fuel pump by bridging the electrical safety circuit.

Plug the plug onto the warm-up regulator.
The control pressure increases (warm-up regulator in the process of shutting off) until the "warm" control pressure is reached.

Test first of all without the application of intake-manifold pressure, then test with simulated intake-manifold pressure (vacuum) in accordance with the values given below:

Test step	Test specifications*
<u>"Warm" control pressure</u>	
Part No. of warm-up regulator:	
0 438 140 005	
• Test with atmospheric pressure (without vacuum)	<u>2.7...3.1 bar</u> (2.8...3.2 kgf/cm ²)
• For testing, connect vacuum pump to intake-manifold-pressure connection of warm-up regulator.	
Setting value: 510...550 mbar (385...415 mmHg)	<u>3.4...3.8 bar</u> (3.5...3.9 kgf/cm ²)

*Pressures in the test-specification table are given in bar (gauge pressure) and/or in kgf/cm² (gauge pressure).



If the measured "warm" control pressure differs from the test specification, this may be due to one of the following faults:

If control pressure too high:

- Fuel delivery for the control-pressure circuit too high.

Test fuel delivery.


Test specification: 160...240 cm³/min.

- Fuel return from the warm-up regulator blocked or constricted. Eliminate constriction.
- Warm-up regulator has hydraulic defect.
Replace warm-up regulator.

If control pressure too low:

- Power supply open-circuit.
Eliminate open circuit. Ensure that the plug is contacting properly.
- Battery voltage too low, voltage drop.
Eliminate voltage drop. Minimum voltage at connector: 11.5 V.
If necessary, repeat test with engine running in order to obtain the normal generator voltage of approx. 14 V when the vehicle is in operation.
- Fuel delivery for the control-pressure circuit too low.
Test fuel delivery.
Test specification: 160...240 cm³/min.
- Warm-up regulator defective. Heating coil open-circuit. Hydraulic defect. Replace warm-up regulator.





438/0048

● Testing the full-load diaphragm for leaks
on warm-up regulator 0 438 140 005

Switch off the electric fuel pump.
Connect the "Mityvac" hand vacuum pump to the intake-manifold-pressure connection port of the warm-up regulator and build up a vacuum.

Setting value: 510...550 mbar (385...415 mmHg).

Max. pressure drop within 15 s 100 mbar (75 mmHg).
If the pressure drop is too great, replace the warm-up regulator.



Finally, check the condition and the correct fitting of the connecting hose from the intake manifold to the warm-up regulator.

If necessary, replace the hose.


When the warm-up regulator has been replaced or a fault remedied, carry out the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinate F 1.

D1

Checking the control pressures
BMW 318i/518i 4-cylinder engine






15. Testing and adjusting the primary (system) pressure:

15.1 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034):

The pressure tester KDEP 1034 is equipped with a three-way valve with 2 separate valve screws. The connections of the directional-control valve are numbered (Fig. a).






Since the end of 1979 the pressure tester KDJE-P 100 has been supplied. Its directional-control valve has only one valve screw (Fig. b). The connections of this directional-control valve are identified by symbols:

- A = Inlet (from the fuel distributor)
- B = Outlet (to the warm-up regulator)

Caution:

When the directional-control valve is not in use, always keep the valve screw(s) open in order to relieve the pressure on the seal rings.



The directional-control valve of the pressure tester is connected into the control-pressure line from the fuel distributor to the warm-up regulator.


The connecting-parts set KDJE-P 100/10 (previously KDEP 1034/10) is additionally required.

Screw the adapter (1) with seal ring to connection port B or 1 of the directional-control valve.

Unscrew the control-pressure line (2) from the fuel distributor and connect to the adapter by means of hollow screw M 8 x 1 and seal rings.

Screw connecting piece (3) of the connecting-parts set onto control-pressure connection port of the fuel distributor and connect with connection port A or 3 of the directional-control valve via connecting hose (4).

Then hang the pressure gauge from the engine hood (perhaps with a wire hook).




15.2 Bleeding the pressure tester

Disconnect the electric plug from the warm-up regulator. Let the pressure gauge hang down (hose fully extended).

Switch on the electrical fuel pump by bridging the electrical safety circuit.

Open and close the valve screw(s) of the directional-control valve in a 10-second rhythm about 5 times.

Then hang the pressure gauge from a suitable support (e.g. from one of the struts under the engine hood). Open valve screw of directional-control valve (both screws in the case of KDEP 1034) (turning to the left).



a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

15.3 Testing the primary pressure:

The test is performed with the engine switched off.
 The temperature of the engine is not important.

Close the valve screw of directional-control valve KDJE-P 100. In the case of KDEP 1034, close valve screw 1, open valve screw 3.

Fuel distributor Part No.	Test specifications - primary pressure (gauge pressure)
0 438 100 078 } 0 438 100 101 }	4.5...5.2 bar (4.6...5.3 kgf/cm ²)

Possible causes for too low a primary pressure:

- Fuel supply faulty
(Delivery of electric fuel pump too low).
- Primary pressure set incorrectly.

A precondition for readjustment of the primary pressure is always that the fuel supply is in order.


Measure the fuel delivery. (Test specification: 750 cm³/30 s.

Possible causes for too high a primary pressure:

- A restriction in the return line leading to the fuel tank.
- Primary-pressure regulator set incorrectly.

For this reason, before readjusting too high a primary pressure, always first check the condition of the return line leading to the fuel tank.






- | | |
|------------------------------|--------------------|
| a = Primary pressure | 4 = Control spring |
| b = From warm-up regulator | 5 = Shim(s) |
| c = Fuel return | 6 = O-ring |
| 1 = Fuel-distributor housing | 7 = Flat seal ring |
| 2 = O-ring. | 8 = Screw plug |
| 3 = Control piston | |

15.4 Adjusting the primary pressure:

Fuel distributor Part No.	Adjustment values - primary pressure (gauge pressure)
0 438 100 078 } 0 438 100 101 }	<u>4.7...4.9 bar</u> (4.8...5.0 kgf/cm ²)





The primary pressure is readjusted by replacing the shims (Item 5).


Note:

0.1 mm more of shim thickness means about 0.15 bar pressure increase and vice versa.

To do this, screw out the large screw plug (Item 8) together with the push valve. After carrying out the adjustment, always fit the screw plug with a new flat seal ring (Item 7) and O-ring (Item 6).

The control piston (Item 3) of the primary-pressure regulator must not be lost. It was matched specially to the fuel distributor housing in the manufacturing plant and therefore is the only part of the primary-pressure regulator which must not be replaced.






16. Testing the entire fuel system for leaks.

16.1 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034):

The pressure tester KDEP 1034 is equipped with a three-way valve with 2 separate valve screws. The connections of the directional-control valve are numbered (Fig. a).






Since the end of 1979 the pressure tester KDJE-P 100 has been supplied. Its directional-control valve has only one valve screw (Fig. b). The connections of this directional-control valve are identified by symbols:

- A = Inlet (from the fuel distributor)
- B = Outlet (to the warm-up regulator)

Caution:

When the directional-control valve is not in use, always keep the valve screw(s) open in order to relieve the pressure on the seal rings.



The directional-control valve of the pressure tester is connected into the control-pressure line from the fuel distributor to the warm-up regulator.

Install using connecting-parts set KDJE-P 100/10 (previously KDEP 1034/10).


Screw the adapter (1) with seal ring onto the outlet fitting B or 1 of the directional-control valve.

Unscrew the control-pressure line (2) from the fuel distributor and connect to the adapter with inlet-union screw M 8x1 and seal rings.

Screw the connecting piece (3) of the connecting-parts set into the control-pressure connection port of the fuel distributor and connect to inlet fitting A or 3 of the directional-control valve via hose line (4).

Suspend the pressure gauge from the engine-compartment lid (possibly using a wire hook).






16.2 Bleeding the pressure tester:

Disconnect the electric plug from the warm-up regulator and the auxiliary-air valve.
 Let the pressure gauge hang down (hose fully extended).
 Switch on the electric fuel pump by bridging the electrical safety circuit.
 Open and close the valve screw of the directional-control valve (valve screw 1 in the case of KDEP 1034) in a 10-second rhythm about 5 times. Then hang the pressure gauge from a suitable support (e.g. from one of the struts under the engine hood).
 Open valve screw of directional-control valve (both screws in the case of KDEP 1034) (turning to the left).





a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

16.3 Leak test

The test is performed with the engine switched off. Make the test with a warm engine but not immediately after the engine has been operated at a high temperature.

Open the valve screw of the directional-control valve (both valves in the case of KDEP 1034).




Switch on the electric fuel pump by bridging the electrical safety circuit until the warm-up regulator has shut off ("warm" control pressure).

Switch the electric fuel pump off again and observe the pressure drop on the pressure gauge.

Test specifications for leaks:

Minimum pressure	20 cm ³ accumulator 0 438 170 007	40 cm ³ accumulator 0 438 170 019/021
after 10 min.:	1.9 bar (2.0 kgf/cm ²)	2.0 bar (2.1 kgf/cm ²)
after 20 min.:	1.7 bar (1.8 kgf/cm ²)	1.7 bar (1.8 kgf/cm ²)





a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

If the pressure drops too quickly, repeat the test with the control-pressure circuit disconnected.

Position of the valve screws:


Close the valve screw of the directional-control valve KDJE-P 100.

In the case of KDEP 1034, close valve screw 1, open valve screw 2.

If the same result is found, the leak is in the primary-pressure circuit.

If the test results are correct during the second test, the leak is in the control-pressure circuit.





- 1 = Electric fuel pump
- 2 = Flat seal ring
- 3 = Tube fitting

16.4 Possible causes of a defect in the primary-pressure circuit:

- Non-return valve in the pressure connection piece of the electric fuel pump has a leak.

Part No. of electric fuel pump: 0 580 254 980

The non-return valve is built into the tube fitting.
If necessary, replace the tube fitting Part No.:
1 583 386 016 as follows:

Thoroughly clean the connection of the delivery line on the electric fuel pump.

Pinch off the intake hose (fuel tank - electric fuel pump) (e.g. using hose clammer W 157 from Matra Co.). Screw off the delivery line, collecting any escaping fuel.


Screw out the defective tube fitting.

Screw a new tube fitting (short end) with thick flat seal ring into the pressure connection piece and tighten to a torque of 17...25 Nm while at the same time applying a wrench to the hexagonal section of the pressure connection piece. Fit a thin flat seal ring, fuel-line inlet union and another flat seal ring onto the long end of the tube fitting and tighten with the hexagon cap nut.

Remove hose clammer from intake hose.

Check connections for leaks with the electric fuel pump in operation.





- The cold-start valve has a leak

Remove cold-start valve. Hose line remains connected.

Hold start valve in a suitable container (e.g. graduate). Switch on the electric fuel pump by bridging the electrical safety circuit.

Dry off the nozzle of the cold-start valve.


No drops must fall from the nozzle of the start valve within the next minute. Even when shaken and knocked, the start valve must not leak.

Switch the electric fuel pump off again.

Replace the cold-start valve if leaky.

Finally, adjust idle speed with the engine at operating temperature. (See Coordinates F 1.)





438/0384

- | | |
|------------------------------|--------------------|
| a = Primary pressure | 4 = Control spring |
| b = From warm-up regulator | 5 = Shim(s) |
| c = Fuel return | 6 = O-ring |
| 1 = Fuel-distributor housing | 7 = Flat seal ring |
| 2 = O-ring | 8 = Screw plug |
| 3 = Control piston | |

- Seal ring (O-ring) on control piston of primary-pressure regulator has a leak.

Replace the seal ring.

Clean the fuel distributor in the region of the primary-pressure regulator.



Unscrew the large screw plug (8) with the complete push-up valve. Also remove the shims (5), control spring (4) and control plunger (3).

Replace the seal ring (O-ring) (2) on the control plunger. Install the control plunger and the control spring.

Screw in the screw plug with the complete push-up valve and with shims (as found when removing) and new seal rings (6 and 7).

Finally, check the primary pressure and, if necessary, adjust by changing the shims (5).

Primary pressure:


Fuel distributor 0 438 100 023

Fuel distributor 0 438 100 074

Checking value 4.5...5.2 bar (4.6...5.3 kgf/cm²) gauge
pressure

Setting value 4.7...4.9 bar (4.8...5.0 kgf/cm²) gauge
pressure






- | | |
|------------------------------|--------------------|
| a = Primary pressure | 4 = Control spring |
| b = From warm-up regulator | 5 = Shim(s) |
| c = Fuel return | 6 = O-ring |
| 1 = Fuel-distributor housing | 7 = Flat seal ring |
| 2 = O-ring | 8 = Screw plug |
| 3 = Control piston | 9 = Push-up valve |

16.5 Possible cause of trouble in the control-pressure circuit

Push-up valve (9) in primary-pressure regulator leaking. The seal ring in the push-up valve is rigidly vulcanized onto the valve needle. If leaking, therefore, it is necessary to replace the complete push-up valve (ready-assembled unit).





438/0420

- | | |
|------------------------------|--------------------|
| a = Primary pressure | 4 = Control spring |
| b = From warm-up regulator | 5 = Shim(s) |
| c = Fuel return | 6 = O-ring |
| 1 = Fuel distributor housing | 7 = Flat seal ring |
| 2 = O-ring | 8 = Screw plug |
| 3 = Control piston | 9 = Push valve |

Clean the fuel distributor in the region of the primary-pressure regulator. Screw out the large screw plug (8) together with the complete push valve. Pay attention to control spring (4) and shims (5). Screw in new push valve using the number of shims (5) as when removed, new O-ring (6) and flat seal ring (7). Finally, check the primary pressure and, if necessary, adjust by changing the shims (5).



Primary pressure, test and setting values (gauge pressure)

Fuel distributor Part No. 0 438 100 078
0 438 100 101

Checking value: 4.5...5.2 bar (4.6...5.3 kgf/cm²)
Setting value : 4.7...4.9 bar (4.8...5.0 kgf/cm²)



17. Testing the injection valves.

Remove the injection valves for testing.

When loosening the fuel lines, apply counter-force at the fixed hexagon of the injection valves.

When refitting the injection valves, it is best to replace the O-rings on the valve stem (BMW- service part) in order to prevent leaks and thus the entry of unmetered air.

17.1 Test equipment and test media

The following testing specification refers to valve testers KDJE-P400 (previously KDEP 7452) and 0 681 200 700.

Observe the test-media specification!

Test media: Calibrating fluid (Shell K 30, Esso-Varsol, Shell Mineral Spirits 135)

or

Bosch Part No. VS 14 942-CH

Former Part No. 5 973 340 650

The calibrating fluid can be obtained in 5 l metal cans from the following supplier:
Firma


Oskar Gnam GmbH & Co

D-7531 Kämpfelbach-Bilfingen

Caution:

For safety reasons, never use normal gasoline or similar easily inflammable and combustible liquids. Even with calibrating fluid, be sure to observe the local official regulations.





17.2 Connecting the injection valve to the tester

Connect the injection valve to the valve tester and bleed the delivery line by operating the lever several times with the union nut open. Then tighten the union nut.


17.3 Checking for dirt

Move the hand lever slowly (about 2 seconds per stroke) back and forth with the stopcock on the pressure gauge open. If the pressure does not build up to 1...1,5 bar gauge pressure, the injection valve has a bad leak (caused, for example, by dirt stuck in it).

You can try to flush the injection valve clear by moving the lever back and forth several times strongly.

If this attempt is successful, continue the test. If it is not possible to flush the valve clear, replace it.





1 = Open

17.4 Testing the opening pressure


Injection valve Part No.	Test specifications - opening pressure (gauge pressure)
0 437 502 006	<u>2,7...3,8 bar</u> (2,8...3,9kgf/cm ²)

E3

Testing the injection valves

BMW 318i/518i 4-cylinder engine





With the stopcock closed, flush the valve out and bleed it with several rapid movements of the lever. Open the stopcock and test the opening pressure by moving the lever slowly (about 2 seconds per stroke).

If the opening pressure is outside tolerance, replace the injection valve. Individual valves can also be interchanged within a set.

17.5 Leakage test

Open the stopcock, build the pressure up slowly to a value 0.5 bar under the opening pressure determined previously (but not less than 2.3 bar gauge pressure), and hold it constant at that level. No drops must now fall from the valve for the next 15 seconds.





438/0058

17.6 Chatter test, evaluation of spray

Move the lever back and forth at about 1 stroke per second. As this is done, the valve must chatter. No drops of fuel must form at the mouth of the valve. The valve must not produce a "cord spray". Formation of a single-sided, atomized spray within an overall spray angle of about 35° is permissible (see example given in illustrations).


Illustration shows good spray formation.





438/0059


Illustration shows single-sided but nevertheless good spray formation.



E6

Testing the injection valves
BMW 318i/518i 4-Cylinder engine





438/0060

Poor spray formation; replace injection valves.


Illustration shows drop formation.

E7

Testing the injection valves

BMW 318i/518i 4-cylinder engine





438/0061

Poor spray formation; replace injection valves.

Illustration shows "cord" spray.





438/0062


Poor spray formation; replace injection valves.

Illustration shows "spray in strands".

If defective injection valves have been replaced, it is necessary finally to adjust the idle speed with the engine at normal operating temperature.

Idle-speed adjustment is described on Coordinates F 19.





18. Comparative measurement of fuel delivery of fuel distributor outlets.

This test is carried out using the tester for delivered quantity comparison KDJE-P 200 (previously KDJE 7451).


18.1 Application

By means of comparative measurements, the differences in the amounts of fuel delivered from the individual outlets on the fuel distributor are determined.

The tester is designed so that the test can be made on the vehicle without having to remove the fuel distributor.

Since the test is made with the original injection valves, the operator can recognize at the same time whether delivered-quantity scatter, if it occurs, is caused by the fuel distributor or by the injection valves.





- 1 = 3-way cock
- 2 = Small rotameter tube
- 3 = Keyboard for 8-way valve
- 4 = Adjusting screw for setting up
- 5 = Spirit level
- 6 = Large rotameter tube
- 7 = Return hose
- 8 = Polyamide hose lines (test lines)

18.2 Construction

The tester is designed for use with all engines, up to 8 cylinders, equipped with K-Jetronic.

Basically, the tester consists of a steel housing containing 2 rotameter tubes with measuring ranges of 2...15 cm³ and 10...180 cm³, an 8-way valve for key operation (Item 3) and a 3-way stopcock (Item 1).


The small rotameter tube (Item 2) is used for the idle measurement while the large tube (Item 6) is used to measure the fuel delivery at part- and full-load. The particular rotameter tube to be used is connected by means of the 3-way stopcock. Using the 8-way valve, the fuel delivery of each cylinder is tested one after the other.

Attached to the tester are 8 hoses (Item 8), each terminated with an automatic connector. When the injection valves are withdrawn from their sockets on the engine they are attached to these connectors. Each automatic connector is fitted with a push valve so that no fuel can escape from connectors that are not in use (when 4- or 6-cylinder systems are tested).

The fuel is returned to the fuel tank through a hose (Item 7) about 5 m long.

The entire test is made with a closed circuit, i.e. no fuel escapes.





- 1 = Fuel distributor injection tubing
- 2 = Injection valves
- 3 = Automatic connectors
- 4 = Tester hoses
- 5 = Return line to fuel tank filler neck

18.3 Setting up and connecting the tester:

Set the tester up beside the engine on a solid base (e.g. on tester trolley KDJE-W 100) and align it with the built-in spirit level at the base of the tester.



Remove injection valves; the injection tubing remains connected.

Before refitting the injection valves check the seals on the valve stem to see whether they are deformed or damaged. If need be, use new seals (Saab service parts) in order to prevent leaks and thus the entry of unmetered air.

Clean the injection valves with a rag and insert injection valves in correct sequence into the automatic connectors of the first four tester hoses.

Note:

Insert the injections valves as far as they will go and tighten the knurled thumbscrews well so that the non-return valves of the automatic connectors are open fully. Introduce the return hose of the tester into the fuel tank filler neck.

18.4 Bleeding the tester:

Remove the rubber hood so that air-flow sensor plate becomes accessible.

Remove the electric plugs from the warm-up regulator and the auxiliary-air device.


Switch on the electric fuel pump by bridging the electrical safety circuit.

Raise the air-flow sensor plate to the stop.

Press the keys on the 8-way valve one after the other, while simultaneously switching the 3-way stopcock until both rotameter tubes are bled.

Return the sensor plate to the rest position.





438/0325

1 = White dot

a = Idle


2 = Measuring line

b = Part load/full load

18.5 Testing

The flow comparison measurement is made in the idle, part-load and full-load ranges.

The small rotameter tube is to be used for the idle measurement (white dot to the left on control knob); part-load and full-load measurements are made using the large rotameter tube (white dot to the right).



438/0325

1 = White dot

a = Idle

2 = Measuring line

b = Part load/full load


The delivered quantities indicated on the rotameter tubes are read off at the top edge of the conical float (Item 2). On testers with a ball float the uppermost point of the ball is used for reading off. With each measurement be sure to wait until the float has reached its final position. This may take 20 ... 30 seconds in the case of small deliveries.

E16

Comparative measurement of fuel delivery

BMW 318i/518i 4-cylinder engine





The exact setting and locating of the position of the air-flow sensor plate for the various load ranges is done using a screwdriver (a small one for the idle position), which is inserted to an appropriate depth between the air funnel and air-flow sensor plate.

E17

Comparative measurement of fuel delivery
BMW 318i/518i 4-cylinder engine




Procedure:

Switch on the electric fuel pump by bridging the electrical safety circuit.

Fixed numerical values are specified in the following test section for the maximum permissible fuel delivery differences for the individual load ranges.

The "setpoint" value always pertains to the fuel-distributor outlet with the lowest fuel delivery, i.e. in each case the outlet with the lowest delivery is to be first ascertained.





Press the key for outlet 1. Pivot the air-flow sensor plate until the corresponding rotameter tube approximately indicates the "set point" value. Fix the air-flow sensor plate in this position.

Test the remaining outlets in order to determine which outlet has the lowest fuel delivery.

Press the key for this outlet again, and set the delivery precisely to the "set point" by correcting the position of the air-flow sensor plate. Then fix the air-flow sensor plate in this position again.

Press the remaining keys one after the other, and determine the maximum fuel delivery of each outlet. A deviation in fuel delivery can only be above the "set point".



18.6 Test specifications

Fuel distributor No.	Set point (cm ³ /min)	Max. permissible fuel delivery (cm ³ /min)
0 438 100 078		
Idle	6.0	6.7
Part load	40.0	43.0
Full load	125.0	137.0

Fuel distributor No.	Set point (cm ³ /min)	Max. permissible fuel delivery (cm ³ /min)
0 438 100 101		
Idle	6.0	6.6
Part load	40.0	43.0
Full load	110.0	121.0

If, in testing, too large a difference is ascertained in one of the three load ranges, the test should for safety's sake be repeated.

If the result is confirmed, you should check whether the fault lies in the fuel distributor or in the injection valves.

To do this interchange the injection valves with the greatest and smallest difference.

If the result is still the same, the fault is in the fuel distributor. If the fault follows the interchanged injection valves, it lies in the injection valves.

Change defective fuel distributor and/or replace defective injection valves.



18.7 Final operations

Re-fit the injection valves properly. Also fit the rubber hood. Make sure that all lines are laid correctly. Re-connect the electrical safety circuit of the K-Jetronic properly.

Use a trial run to check that there are no leaks in line connections.

Finally check the idle-speed adjustment; if necessary, correct. Idle adjustment is described on Coordinates F 1.



19. Idle adjustment

19.1 Test conditions:

- Warm up the engine before making the idle adjustment

Important note:

- If fuel-injection tubing or injection valves were loosened or removed, the engine should be warmed up under load. The low rate of fuel flow during idling is not always adequate to drive all the air out of the fuel-injection tubing.
- The idle speed must not be adjusted when the engine is too hot, e.g. immediately after being raced or after a power measurement on the roller-type test stand.
- In vehicles with an air conditioner, this should be switched off to stabilize the engine speed during idle-speed adjustment.

Check that the throttle-plate lever is up against the idle stop. The cable should be free of tension.

Rotational-speed measurement with separate tachometer.



19.2 Additional test conditions for engines of Sweden and Australia models

These engines are equipped with the following emission control systems: exhaust-gas recirculation and Pulsair secondary-air induction.

Both systems must be rendered inoperative before performing the idle adjustment.

The following coordinates describe how to do this.

Operation

- Exhaust-gas recirculation


With exhaust-gas recirculation, some of the exhaust gases are returned from the exhaust system to the intake system in order to take part once again in combustion. This reduces the proportion of nitrogen oxides in the exhaust gas. Exhaust-gas recirculation is controlled by an exhaust-gas recirculation valve as a function of intake-manifold pressure and engine temperature.

- Pulsair secondary-air induction

With this system, unburned gases in the exhaust are after-burned by the injection of air, thus reducing the pollutants in the exhaust gas.

The system does not employ a secondary-air pump, but uses the pulsation in the alternation between overpressure and depression in the exhaust system. When there is a depression, auxiliary air is drawn into the exhaust manifold. When there is overpressure, non-return valves prevent exhaust gas from flowing back to the air filter.





The Pulsair secondary-air induction and exhaust-gas recirculation systems must be rendered inoperative before performing the idle adjustment.

Pulsair secondary-air induction:

A = Non-return valve
B = From air filter

Remove the hose of the non-return valve on the air filter and seal off tight with a plug.

Exhaust-gas recirculation:

C = Thermo-valve
D = Solenoid-operated valve
E = Speed relay
F = Recirculation valve
G = Pressure converter

Remove the vacuum-control hoses from the recirculation valve and seal off tight.

F3

Idle adjustment

BMW 318i/518i 4-cylinder engine




F4

Idle adjustment

BMW 318i/518i 4-cylinder engine





19.3 Adjusting the idle speed


The idle speed is adjusted with the air filter fitted at the bypass screw (arrow) on the throttle-valve assembly.

F5

Idle adjustment

BMW 318i/518i 4-cylinder engine





438/0389

19.4 Adjusting the CO concentration

The CO concentration is adjusted by turning the idle-mixture-adjusting screw (1) in the mixture-control unit using the adjusting wrench KDEP 1035.

After removing the safety cap (3) of the guide tube (2), the adjusting wrench is passed through the guide tube and inserted into the idle-mixture-adjusting screw.

Turning to the right = richer mixture

Turning to the left = leaner mixture

Caution:

Always make the adjustment from the lean side, i.e. if the mixture is too rich turn the idle-mixture-adjusting screw further to the left than necessary and then turn it to the right up to the setting required.

After every adjustment remove the adjusting wrench and accelerate the engine briefly, so that the air-intake system can cool off. Then wait until the indicator of the CO tester has stabilized. Never accelerate the engine with the wrench still in place as this could result in bending the control lever in the air-flow sensor.

F7

Idle-speed adjustment

BMW 318i/518i 4-cylinder engine



19.5 Anti-tamper device for idle-mixture-adjusting screw:

In the Federal Republic of Germany, § 47 of the FMVSS/CUR, "Exhaust Gases and their Discharge", has been amended. This amendment order was printed in full in the Verkehrsblatt 13 of 15th July 1975.

Accordingly, all motor vehicles with externally supplied ignition produced as of 1 October 1976 must be provided with anti-tamper devices for the idle-mixture-adjusting screw so that it is not possible to adjust the screw without destroying the anti-tamper device. The intention is to prevent non-experts from re-adjusting the idle setting and thus inadmissibly influencing the exhaust gas. Consequently, the anti-tamper caps may only be used in the workshop and must not be sold to customers for their own use.

These anti-tamper caps come in different colors. The cap to be used for the after-sales service of updraft air-flow sensors is red.

It can be obtained from Bosch under part number 3 430 522 002.

The bore of the setting device (for receiving the adjusting wrench) is sealed by a plug.

The anti-tamper device for the air-flow sensor is removed and fitted using special tools (e.g. No. 131 090 from Cartool Co., Hans Schubert KG, Unterer Grasweg 88, D-8070 Ingolstadt).



19.6 Test specifications and settings for idle adjustment:

Conditions

- Engine at normal operating temperature.
- Air conditioner switched off.
- Exhaust-gas recirculation and Pulsair secondary-air induction systems (on Sweden and Australia models) inoperative.

Idle speed

318i Europe model 850...950 min⁻¹

318i/518i Sweden, Australia model 900...1000 min⁻¹

CO concentration

318i Europe model 0.5...1.5 % by vol.

318i/518i Sweden, Australia model 1.0...2.0 % by vol.

Finally, re-connect the hose of the Pulsair secondary-air induction system and the vacuum-control hoses of the exhaust-gas recirculation system.



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

Packaging of goods under warranty

K-Jetronic (CIS)

438

VDT-I-438/101 B
10. 1976

All components or assemblies of the K-Jetronic which are dispatched under warranty must be correctly and carefully packaged so that no further damage or impairments occur during transit, since these would not be covered by warranty.

Any fuel remnants must be removed from those K-Jetronic assemblies intended for dispatch, so as to eliminate any danger of fire during transit.

The intake openings and outlets of the assemblies must be sealed off with caps or plugs. As new products were fitted, the caps or plugs from these may be used.

The plunger of the fuel distributor is to be fitted with a protective cap of adequate size, or secured to the fuel distributor.

In addition, the assemblies are packed in tightly packed, well-sealed plastic sleeves. Fuel distributors and warm-up regulators are packed individually.

If components arrive damaged due to incorrect packaging or do not comply with these instructions, they can be returned and the warranty claim rejected.

BOSCH

Geschäftsbereich KH, Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50. Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L1

Technical Bulletin

BMW 318i/518i 4-cylinder engine



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

Securing of idle-speed adjusting screws

K-Jetronic (CIS)

438

VDT-I-438/102 B
11.1976

According to a statutory regulation, changes have been made to § 47 of the German traffic licensing laws concerning exhaust gases and their outlets. This regulation was printed in full in traffic law sheet 13 of 15.7.75.

Consequently, all motor vehicles with external-ignition engines must have their idle-speed adjusting devices secured from the 1st October 1976, so that adjustment of the screw is impossible without destroying the securing device. This should stop unskilled people from adjusting the installation of the idle-speed system and thereby illegally influencing the emission values. As from now, securing caps can only be used in the workshop and cannot be sold to customers for their own use.

Securing caps are produced in various colors. For after-sales service the following caps and colors are used:

downdraft air-flow sensor

Blue

securing cap is not available from BOSCH.

Part number is DB 000.997.59 86 from the

Deutsche Vergaser Gesellschaft K 34 520

updraft air-flow sensor

Red

Part number 3 430 522 002

These stipulations are only valid in countries where ECE regulations (Economic Commission for Europe) apply. The air-flow sensors must however be converted for the use of these securing caps, as a matter of principle. The caps can also be used in countries not subject to ECE regulations, to prevent dirt penetrating through the pipe to the adjustment in the case of updraft air-flow sensors.

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L2

Technical Bulletin

BMW 318i/518i 4-cylinder engine



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

EXCHANGEABLE NON-RETURN VALVES
in electric fuel pumps 0 580 254 ..

VDT-I-438/104 En
5.1982
(replaces Ed. 3.1982)

Electric fuel pump	Parts set (non-return valve + seal ring)	Non-return valve	Seal ring
0 580 254 001	1 587 010 500	---	---
.. 002	.. 500	---	---
.. 950 }	1 587 010 006	---	---
.. 951 }	1 587 010 002	---	---
.. 952	.. 501	---	---
.. 953	.. 002	---	---
.. 954	.. 002	---	---
.. 956	.. 002	---	---
.. 957	.. 002	---	---
.. 958	.. 002	---	---
.. 959	.. 002	---	---
.. 960	.. 002	---	---
.. 961	.. 002	---	---
.. 962	.. 002	---	---
.. 963	.. 005	---	---
.. 964	.. 002	---	---
.. 965	.. 002	---	---
.. 966	.. 002	---	---
.. 967	.. 002	---	---
.. 968	.. 002	---	---
.. 969	.. 002	---	---
.. 970	.. 002	---	---
.. 971	.. 002	---	---
.. 972	.. 002	---	---
.. 973	.. 002	---	---
.. 974	.. 002	---	---
.. 975	.. 003 4	---	---
.. 976	.. 004 3	---	---
.. 977	.. 004 3	---	---
.. 978	1 587 410 901	---	---
.. 979	010 004 3	---	---
.. 980	.. 002	---	---
.. 981	.. 002	---	---

3 = Parts set ... 003 also possible (delivery line connection at 90°)

4 = Parts set ... 004 also possible (delivery line connection axial)



BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
C by Robert Bosch GmbH D-7 Stuttgart 1 Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L3

Technical Bulletin

BMW 318i/518i 4-cylinder engine



Electric fuel pump	Parts set (non-return valve + seal ring)	Non-return valve	Seal ring
.. 982 1	.. 003 4	---	---
.. 982 2	1 587 410 901	---	---
.. 984	010 004 3	---	---
0 580 254 985	---	1 583 385 006	1 580 203 002
.. 986	---	.. 386 011	.. 001
.. 987	--- 008	.. 001
.. 988	--- 008	.. 001
.. 989	--- 008	.. 001
.. 990	---	.. 385 004	.. 002
.. 991	---	.. 004	.. 002
.. 992	1 587 010 001	---	---
.. 996	---	.. 386 011	.. 001
.. 998	---	.. 385 004	.. 002

1 = until FD 822 2 = from FD 823

3 = Parts set ... 003 also possible (delivery line connection at 90°)

4 = Parts set ... 004 also possible (delivery line connection axial)

Please direct questions and comments concerning the contents to our authorized representative in your country.



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

HOT-STARTING PROBLEMS

438

VDT-I-438/105 En

3.1980

K-Jetronic

Replaces Ed. 2.1980

Hot-starting problems can occur in various vehicles fitted with K-Jetronic. This means that when an engine is switched off whilst still hot and then switched on again after a short period, it does not start as well as it should.

The engine, the ignition system and the K-Jetronic system in these vehicles should be carefully checked. With the K-Jetronic particular attention should be paid to the:

- complete system (in case of leaks),
- injection valves (in case of leaks),
- correct position of the air-flow sensor plate (rest position).

Instructions can be found in the vehicle-related repair manuals VDT-W-438/5...

If the engine still does not start satisfactorily when hot, even after checking, a timing relay can be fitted in K-Jetronic systems which are not equipped with a solenoid valve for reducing the control pressure as additional starting help.

Timing relay 0 340 000 003 controls the start valve during hot starts. The start valve then injects extra fuel intermittently (sometimes cutting out completely).

The timing valve is fitted according to the wiring diagram (see reverse side). The fitting of this relay will be charged for.

After fitting the timing relay starting should be carried out as follows:

Vehicles with start valve in intake manifold - with open throttle valve,
Vehicles with start valve in idle duct - with closed throttle valve.

BOSCH


Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH D-7 Stuttgart 1 Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L5

Technical Bulletin


BMW 318i/518i 4-cylinder engine





K-Jetronic system with post-injection relay

- 1 = Timing relay 0 340 000 003
- 2 = Post-injection relay
- 3 = Thermo-time switch
- 4 = Start valve



K-Jetronic system without post-injection relay



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

EXPORT VEHICLES WITH

EMISSION CONTROL SYSTEMS

VDT-I-Gen. 042 En.

12. 1981

K-Jetronic and L-Jetronic

Export vehicles for countries with stringent exhaust emission regulations are equipped with various emission control systems. To meet the legal requirements, these systems are installed either individually or in combination, depending on the model version.

Emission control system	installed predominantly in export vehicles				
	Sweden	Australia	Canada	USA	Japan
Exhaust-gas recirculation*	●	●	●	(●)	(●)
Secondary-air induction*	●	●	●	(●)	(●)
Secondary-air injection*	●	●	●	(●)	(●)
Catalytic converter*	-	-	-	●	●
Lambda closed-loop control	-	-	-	●	●

The vehicle-related After-Sales Service Instruction Manuals for the K-Jetronic and L-Jetronic describe the construction, function and operating principle of the emission control systems. The influence of these systems should be borne in mind particularly when adjusting the idle speed and CO concentration.

Export vehicles are sometimes also encountered in countries which do not have particularly stringent exhaust emission legislation. This Service Information publication summarizes the various emission control systems and provides information for the After-Sales Service in countries with exhaust emission legislation which does not require such emission control systems or unleaded fuel.

* Not made by Bosch

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
by Robert Bosch GmbH D-7 Stuttgart 1 Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH


L7

Service Information

BMW 318i/518i 4-cylinder engine



1. Exhaust-gas recirculation (EGR)



1 = Exhaust-gas recirculation valve

2 = Thermo-valve


Some of the exhaust gas is returned to the intake manifold via a vacuum-controlled exhaust-gas recirculation valve. This recirculation of exhaust gas into the combustion chamber lowers the combustion temperature and reduces the emission of nitrogen oxides (NO_x). The thermo-valve and the position of the vacuum tapping port on the throttle-valve assembly ensure that exhaust gas is only recirculated when the engine is warm and only at part load. There is a reduction in engine speed of about 200 min⁻¹. Exhaust-gas recirculation is inoperative at idle, full-load and when the engine is cold.

When testing or adjusting the idle speed and CO concentration, remove and seal off the vacuum control line (arrow) on the exhaust-gas recirculation valve in order to ensure that the exhaust-gas recirculation system is inoperative.

In countries without stringent exhaust emission legislation it is not necessary to shut down the system.



2. Secondary-air induction (e.g. Volvo Pulsair system)



1 = Non-return valve

2 = Air filter


The pulsating alternation between overpressure and depression in the flow of exhaust gas inducts fresh air into the exhaust ports via a non-return valve. Unburned residues of carbon monoxide (CO) and hydrocarbons (HC) are partially after-burned, leading to fewer pollutants in the exhaust gas.

When testing or adjusting the idle speed and the CO concentration, the secondary-air induction system must be rendered inoperative. To do this, remove the hose between the non-return valve and the air filter on the air filter (arrow) and seal off tight with a plug.

In countries without stringent exhaust emission legislation it is not necessary to shut down the secondary-air induction system.



3. Secondary-air injection



1 = Non-return valve

3 = Change-over valve

2 = Air filter

4 = Air pump


An air pump driven by the engine inducts fresh air through the air filter and forces it via a non-return valve into the exhaust ports. As in the case of secondary-air induction, there is a partial after-burning of the CO and HC residues. This makes the exhaust gas cleaner. A vacuum-controlled change-over valve controls the operation of the secondary-air injection system.

When testing or adjusting the idle speed and the CO concentration, shut down the secondary-air injection system. To do this, remove the hose from the outlet of the change-over valve (arrow) and seal off tight with a plug.

In countries without stringent exhaust emission legislation it is not necessary to shut down the secondary-air injection system.



4. Catalytic converter



1 = Catalytic converter

2 = Intermediate pipe

The single-bed catalyst installed in the exhaust system in export vehicles (also with lambda closed-loop control) reduces all three pollutants CO, HC and NO_x to a minimum. The catalytic surface triggers chemical reactions of the pollutants, rendering them non-toxic.

Important: Proper operation only possible in conjunction with unleaded fuel (at present only in USA and Japan).

When testing or adjusting the idle speed and the CO concentration, the catalytic converter can be neglected since the exhaust-measuring point is upstream of the catalyst.


Caution!

If the vehicle is operated on leaded fuel (predominantly in countries without stringent exhaust emission legislation) the catalytic converter must be removed. If not removed, the catalytic converter would become clogged up and lead to a reduction in the power output of the engine.

Appropriate intermediate pipes for converting the exhaust system are available from the vehicle manufacturer.



5. Lambda closed-loop control



1 = Lambda sensor
2 = Plug

3 = Control unit
4 = Timing valve

5 = Catalytic converter
6 = Intermediate pipe

Export vehicles for the USA and Japan are equipped with lambda closed-loop control. This additional function of the K-Jetronic or L-Jetronic is not a downstream emission control system, but ensures a low pollutant content in the exhaust gas by means of optimum mixture preparation. Additional exhaust-gas recirculation, secondary-air induction or secondary-air injection is therefore not necessary in most cases. Like the catalytic converter, the lambda sensor (in the exhaust gas) operates only with unleaded fuel.

If the vehicle is operated on leaded fuel, the lambda sensor becomes clogged up and ceases to operate. The control unit detects this and switches from closed-loop to open-loop control. The system then operates on a fixed air-fuel ratio in the same manner as a K-Jetronic or L-Jetronic without lambda-closed-loop control. Before operating on leaded fuel, the lambda sensor should be removed and the installation hole should be closed off with a screw plug M18x1.5 (length of thread max. 8.5 mm). The disconnected plug (2) of the sensor connecting cable should be insulated and fastened to a suitable place on the vehicle body.

Caution!

Under no circumstances must the control unit or the timing valve be shut down on the lambda closed-loop control of the K-Jetronic.

The catalytic converter should be replaced by an intermediate pipe.

Published by:
Robert Bosch GmbH
Division KH
After-Sales Service Department
for Training and Technology
(KH/VSK)



Table of contents

<u>Section</u>	<u>Coordinates</u>
Microfiche layout.....	A 1
1. Test specifications.....	A 2-A 6
2. Electrical safety circuit.....	A 7-A 10
3. Diagram of fuel lines.....	A 11-A 14
4. General information.....	A 15-A 16
5. Test equipment and tools.....	A 19-A 20
6. Installation position of individual components.....	A 21-A 24
7. Trouble-shooting chart.....	B 1-B 4
8. Testing the air-intake system of the engine for leaks.....	B 5-B 6
9. Testing the control lever in the air- flow sensor and the control plunger in the fuel distributor for ease of movement.....	B 7-B 16
10. Testing and adjusting the position of the air-flow sensor plate.....	B 17-B 21



Table of contents (continued)

<u>Section</u>	<u>Coordinates</u>
11. Checking the operation of the auxiliary-air device.....	B 22-B 23
12. Checking the operation of the electric fuel pump.....	C 1- C 4
13. Checking the cold-start system (thermo-time switch, start valve)	C 5-C 8
14. Testing the control pressures (warm-up regulator).....	C 9-D 1
14.3 Testing the fuel delivery for the control-pressure circuit.....	C 11-C 12
14.4 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034).....	C 13-C 14
15. Checking and adjusting the primary pressure.....	D 2-D 9
16. Checking the overall fuel system for leaks.....	D 10-D 24
17. Testing the injection valves.....	E 1-E 9



Table of contents (continued)

<u>Section</u>	<u>Coordinates</u>
18. Comparison of delivered quantities...	E 10-E 21
18.3 Setting up and connecting the tester for delivered quantity comparison KDJE-P 200 (previously KDJE 7451)....	E 13-E 14
19. Idle-speed adjustment..... Technical Bulletins and Service Information	F 1-F 9 L 1-L 12

© 1982 Robert Bosch GmbH
Automotive Equipment - After-Sales Service,
Department for Technical Publications KH/VDT,
Postfach 50, D-7000 Stuttgart 1

Published by: After-Sales Service, Department for
Training and Technology (KH)VSK). Press date: 4.1982

Please direct questions and comments concerning the
contents to our authorized representative in your
country.

This publication is only for the use of the Bosch
After-Sales Service Organization, and may not be passed
on to third parties without our consent.

Microfilmed in the Federal Republic of Germany.
Microphotographié en République Fédérale d'Allemagne.

